

PICMG 1.3 Single Host Board

Version 1.5

Copyright © Portwell 2016

ROBO-8113VG2AR User's Guide

Revision History

R1 0	Preliminary
1(1.0	
R1.1	
R1.2	Page22 J1 mark 標記有誤
R1.3	Page11 add VGA resolution limitation
R1.4	Page12 add Soft reminder about power supply discharge
R1.4-1	Page11 add Noted 2 about VGA limit with external cable
R1.5	Update JP6 ATX/AT select pin information

Contents

1	Introduction		
2	Specific	cations	11
	2.1	Supported Operating Systems	
	2.2	Mechanical Dimensions	
	2.3	Power Consumption	
	2.4	Environmental Specifications	
3	Hardwa	are Configuration	
	3.1	Jumpers and Connectors	
	3.2	Jumpers Settings	
	3.3	Connector Settings	
4	Signal [Descriptions	
	4.1	Watch Dog Signal	
	4.2	GPIO Signal	
5	System	Resources	
	5.1	Intel® Skylake-S PCH	
	5.2	Main Memory	
	5.3	Installing the Single Board Computer	
	5.3.1	Chipset Component Driver	
	5.3.2	Intel® HD Graphics 530	
	5.3.3	Intel LAN I210AT/I219LM Gigabit Ethernet Controller	

6	BIOS Setup Items		
	6.1	Introduction	. 35
	6.2	BIOS Setup	. 35
	6.2.1	Main	. 37
	6.2.2	Configuration	. 39
	6.2.3	Security	. 83
	6.2.4	Boot	. 85
	6.2.5	Save & Exit	. 87
7	Troubles	hooting	. 89
	7.1	Hardware Quick Installation	. 89
	7.2	BIOS Setting	. 91
	7.3	FAQ	. 92
8	Portwell	Software Service	. 97
9	Industry	Specifications	. 98
	9.1	Industry Specifications	. 98

Preface

This user's guide provides information about the components, features, connectors and BIOS Setup menus available on the ROBO-8113VG2AR. This document should be referred to when designing PICMG 1.3 application. The other reference documents that should be used include the following:

♦Intel SkyLake-S/KabyLake-S Design Guide

Intel SkyLake-S/KabyLake-S Specification

Please contact Portwell Sales Representative for above documents.

Disclaimer

The information contained within this user's guide, including but not limited to any product specification, is subject to change without notice. Portwell provides no warranty with regard to this user's guide or any other information contained herein and hereby expressly disclaims any implied warranties of merchantability or fitness for any particular purpose with regard to any of the foregoing. Portwell assumes no liability for any damages incurred directly or indirectly from any technical or typographical errors or omissions contained herein or for discrepancies between the product and the user's guide. In no event shall Portwell be liable for any incidental, consequential, special, or exemplary damages, whether based on tort, contract or otherwise, arising out of or in connection with this user's guide or any other information contained herein or the use thereof.

Trademarks

Product names, logos, brands, and other trademarks featured or referred to within this User's guide or the Portwell website, are the property of their respective trademark holders. These trademark holders are not affiliated with Portwell, our products, or our website.

Warranty

Portwell makes no representation, warranty or guaranty, express or implied regarding the products except its standard form of limited warranty ("Limited Warranty"). Portwell may in its sole discretion modify its Limited Warranty at any time and from time to time.

Beginning on the date of shipment to its direct customer and continuing for the published warranty period, Portwell represents that the products are new and warrants that each product failing to function properly under normal use, due to a defect in materials or workmanship or due to non conformance to the agreed upon specifications, will be repaired or exchanged, at Portwell's option and expense.

DOON

Certification

Portwell is certified to DIN EN ISO 9001:2000 standard.

Technical Support

Portwell technicians and engineers are committed to providing the best possible technical support for our customers so that our products can be easily used and implemented.

We request that you first visit our website at <u>http://www.portwell.com.tw/support/</u> for the latest documentation, utilities and drivers, which have been made available to assist you. If you still require assistance after visiting our website then contact our technical support department by email at_ tsd@mail.portwell.com.twfor further assistance. Thank you!

Notice SBC Handling and Installation Notice

■ Handling and Installing SBC

Caution: Do not just hold any single side of the SBC; hold evenly on both sides!

- •Heavy processor cooler may bend the SBC when SBC being held just on one side.
- The bending may cause soldering or components damaged.





■ Fix your SBC in System

Caution: Suggest your S.I or vendor to use a metal bracket to hold/fix the desktop or server grade SBC to avoid the vibration damage during transportation. Heavy processor cooler may bend the SBC when systems are during transportation without any holder.

Example:

- 4U chassis :
 - → Use L type mental or plastic or rubber bracket to hold SBC.



Copyright © Portwell 2016

• 2U or 1U chassis: a mental bracket on the bottom of chassis to balance and support SBC from bending.



Copyright © Portwell 2016

ROBO-8113VG2AR User's Guide

1 Introduction

ROBO-8113VG2AR, a PICMG 1.3 Single Host Board (SHB) with the latest Intel 7th and 6th Generation Core processors supported from E3 class Xeon processors to Core i3 processors. Portwell's ROBO-8113VG2AR implements flexible PCI Express Gen 3 expansion by one PCI Express x16 or two PCI Express x 8 or one PCI Express x8 and two PCI Express x4 with dedicated processor sku, which is ideal for a range of applications, such as Industrial Automation, Digital Signage, and Medical.

ROBO-8113VG2AR adopt Intel C236 and Q170 PCH. Providing up to 32GB DDR4 system memory supported with ECC or non-ECC option. ROBO-8113VG2AR with the 7th and 6th generation Intel® processor family features and integrated, enhanced graphics engine which provides significant 3D performance, up to DirectX® 12. It supports triple display function via DVI-I (VGA and DVI-D) and HDMI up to 4Kx2K. Rich I/O functions are also provided by ROBO-8113VG2AR single host board, which is 10x USB 3.0, 2x USB 2.0, 6x SATA III ports (dual ports via backplane), 2x RS232 ports, 2x smart COM ports which select RS232/422/485 mode by bios adjustment, and dual Intel GbE LAN ports. It also supports on board TPM 2.0 to secure your applications.

For the industries who already have large install based systems, ROBO-8113VG2AR not only provides a way to upgrade to use the latest Intel processors, but also supporting legacy elements such as VGA, four PCI expansion, four Serial ports and PS/2 Keyboard and Mouse.

2 Specifications

Main Processor	 Intel® Kaby Lake-S/Skylake -S E3-12xxv5/v6 and Core™ i Processors 	
System BIOS	◆ AMI UEFI BIOS	
Main Memory	 Up to 32 GB ECC or non-ECC DDR4 on two Long-DIMM sockets. Supports dual channel DDR4 1866/2133 MHz SDRAM 	
Graphics	 Controller: Intel® Gfx Gen 9, HD graphics VGA: Resolution up to 1920 x 1200 @ 60Hz DVI-D: Resolution up to 1920 x 1200 @ 60Hz (VGA+DVI-D on bracket by DVI-I port) Note 1(VGA resolution limitation) If use the B6903351(DVI-D +VGA Y cable) to connect with DVI-D & VGA monitor simultaneously, the VGA resolution only can up to 1920x1080.And only DVI-D can be to show correct information about type of monitor & resolution. Note 2 (VGA limit with external cable) When using external Y cable (or DVI to VGA cable only) to connect with a VGA screen, and has 	
	requirement for USB3.0 on REAR I/O, we recommended using USB3.0 J17 port (On board	
	USB3.0 is without limitation)	
	♦ HDMI: Resolution up to 4096 x 2160 @ 24Hz	
Expansion Interface	From CPU: 1x PCI Express x16 or 2x PCI Express x8 or 1x PCI Express x8 + 2x PCI Express x4 by jumper setting (Gen3 up to 8.0 GT/s)	
	◆ From PCH: 1x PCI Express x4 or 4x PCI Express x1 by amerent bios support (Gen 3 up to 8.0 G1/S)	
SATA Interface	 Six SATA III ports (SATA 6Gb/s), dual ports via backplane 	

Input/Output	 Serial Ports: 2x RS-232 & 2x RS-232/422/485 selectable by bios USB Port: 2x USB 3.0 on bracket, 8x USB 3.0 on board header, 4x USB 2.0 ports through backplane GPIO connector: 8GPI + 8GPO Audio Interface: Mic-In / Line-Out / Line-in (on-board header) 	
Ethernet	 ◆ Supports dual 10/100/1000 Mbps Ethernet port (s) via PCI Express x1 interface by Intel WGI219LM and WGI210AT controller ◆ Dual RJ45 connector on bracket 	
ТРМ	◆ On-board TPM 2.0 support (TPM IC: Infineon SLB9665TT2.0)	
High Drive GPIO	◆ One pin-header for GPIO (8bit in &8bit out)	
Mechanical and environmental specifications	 Operating temperature: 0 ~ 60° C Storage temperature:-20 ~ 80° C Humidity: 5 ~ 90% non-condensing Power supply voltage: ATX Soft reminder 	
	 Because the power supply discharge sequence is not standardized, the difference between the 5v / 3.3v discharge sequence during shutdown ,maybe cause malfunction or abnormal waveform. ◆ Board size: 338.5mm x 126.39mm, 13.33" (L) x 4.98" (W) 	

2.1 Supported Operating Systems

The ROBO-8113VG2AR supports the following operating systems.

♦ Windows 7 support

♦ Windows 8.1 / WEI 8.1 support

♦ Windows 10 full support

♦ Kernel.org Distribution

2.2 Mechanical Dimensions



Copyright © Portwell 2016

ROBO-8113VG2AR User's Guide



2.3 Power Consumption

Test Configuration			
CPU Type	Type Intel® Core™ i5-6500TE CPU @ 3.2GHz (ES) L3: 6MByte		
SBC BIOS	Portwell, Inc. ROBO-8113VG2AR-Q170-PCIE1 TEST BIOS (60105T00)		
Memory	WARIS UB-DIMM DDR4 2133 8GB*2 (SEC K4A4G085WD)		
VGA Card	Onboard Intel® HD Graphics 530		
VGA Driver	Intel® HD Graphics 530 Version: 20.19.15.4312		
LAN Card	Onboard Intel® Ethernet Connection(2) I219-LM		
LAN Driver	Intel® Ethernet Connection(2) I219-LM Version: 12.13.17.7		
LAN Card	AN Card Onboard Intel® I210 Gigabit Network Connection		
LAN Driver	Intel® I210 Gigabit Network Connection Version: 12.14.7.0		
Audio Card	Onboard Realtek ALC886 High Definition Audio		
Audio Driver	Realtek ALC886 High Definition Audio Version: 6.0.1.7312		
Chip Driver	Chip Driver Intel® Skylake-S Chipset Device Software Version: 10.0.27		
USB3.0 Driver	Intel® USB 3.0 eXtensible Host Controller Adaptation Driver Version: 1.0.1.45		
EC Version	51124T00 (11/24/2015)		
CDROM	Pioneer DVR-S19LBK		
Power Supply	FSP460-60PFB 460W		
Carrier Board	PBPE-11A3		
USB3.0 HDD	SP Armor A30		
SATA SSD	PLEXTOR DRAH1T-A74658844		

Copyright © Portwell 2016

Power consumption			
ltem	Power ON	Full Loading 10Min	Full Loading 30Min
CPU +12V	1.09A	2.46A	2.38A
System +12V	0.31A	0.41A	0.38A
System +3.3V	1.27A	1.01A	1.02A
System +5V	1.19A	1.63A	1.63A
System+ Device +12V	0.40A	0.94A	0.89A
System+ Device +5V	2.39A	2.64A	2.68A

2.4 Environmental Specifications

Storage Temperature : -20~80°C Operation Temperature : 0~60°C Storage Humidity : 5~90% Operation Humidity: 10~90% Block Diagram



Copyright © Portwell 2016

ROBO-8113VG2AR User's Guide

3 Hardware Configuration

3.1 Jumpers and Connectors

This chapter indicates jumpers', headers' and connectors' locations. Users may find useful information related to hardware settings in this chapter.



Copyright © Portwell 2016

ROBO-8113VG2AR User's Guide

3.2 Jumpers Settings

For users to customize ROBO-8113VG2AR's features. In the following sections, Short means covering a jumper cap over jumper pins; Open or N/C (Not Connected) means removing a jumper cap from jumper pins. Users can refer to Figure 1 for the Jumper allocations.

Jumper Table

The jumper settings are schematically depicted in this manual as follows:

Jump Function List:

Jumper	Function	Remark
JP1	Configure PCIEx16, x8 (For C236/Q170 only)	Header2Px2/2.54mm
JP2	Auto Power Button(Reserve)	PH2Px1/2.54mm
JP3	LPC 80 Port Pin Header	Header5Px2/2mm
JP4	Clear CMOS Setup	PH3Px1/2.54mm
JP5	WDT Enable/Disable Pin	PH2Px1/2.54mm
JP6	ATX/AT Select Pin	PH3Px1/2.54mm

JP1: PCI Express* Bifurcation



JP4: Clear CMOS Setup



PIN No.	Description
1-2, Short	Normal
2-3, Short	Clear CMOS

JP5: WDT Enable/Disable Pin



PIN No.	Description	
1-2 Short	WDT Enable	
1-2 Open	WDT Disable	

JP6: ATX/AT Select Pin



PIN No.	Description	
1-2 Short	AT mode	
2-3 Short	ATX mode	

3.3 Connector Settings

Connector Allocation

I/O peripheral devices are connected to the interface connectors

Connector Function List

Connector	Function	Remark
J1	Keyboard/Mouse Connector	Header 5Px2/2.54mm
J2/J7/J15/J16	SATA Connector	
J3/J4/13/14	USB2.0/3.0 connector	
J5	HDMI Connector	
J6	DDR4 Channel B Slot	
J8	DDR4 Channel A Slot	
J9	SM Bus Pin Header	PH5Px1/2.54mm
J10	Front Panel Pin Header	Header 8Px2/2.54mm
J11	GPIO Pin Header	Header 5Px2/2.54mm
J12	ATX 8 Pin Connector(For CPU Power)	
J17/J20	USB2.0/3.0 connector(D-Sub)	
J18	COM1 Pin Header	
J19	COM2 Pin Header	

Copyright © Portwell 2016

J21	RJ45 Connector for I210	
J22	COM4 Pin Header	
J23	COM3 Pin Header	
J24	RJ45 Connector for I219	
J25	CPU Fan	
J26	DVI-I Connector	
J27	Audio Pin Header	Header 5Px2/2.54mm
J28	System Fan	

J1: Keyboard/Mouse Connector

123.			
9	0	0	
	1000 A	100	-
	0	0	0

PIN No.	Signal Description	PIN No.	Signal Description
1	Mouse Data	2	Keyboard Data
3	N/C	4	N/C
5	Ground	6	Ground
7	PS2 Power	8	PS2 Power
9	Mouse Clock	10	Keyboard Clock

J2/J7/J15/J16 : SATA Connector



PIN No.	DESCRIPTION
1	Ground
2	TX_P
3	TX_N
4	Ground
5	RX_N
6	RX_P
7	Ground

J3/J4/13/14: USB2.0/3.0 connector



PIN No.	Description	PIN No.	Description
1	5V_Dual		
2	USB3.0_RX_N	19	5V_Dual
3	USB3.0_RX_P	18	USB3.0_RX_N
4	Ground	17	USB3.0_RX_P
5	USB3.0_TX_N	16	Ground
6	USB3.0_TX_P	15	USB3.0_TX_N
7	Ground	14	USB3.0_TX_P
8	USB2.0_N	13	Ground
9	USB2.0_P	12	USB2.0_N
10	Ground	11	USB2.0_P

J9: SM Bus Pin Header



PIN No.	Description
1	Clock
2	NC
3	Ground
4	Data

Copyright © Portwell 2016

J10: Front Panel Connector



		PIN	
PIN No.	Description	No.	Description
1	PWR_LED (+)	2	VCC
3	PWR_LED (-)	4	NC
5	l219_LAN (+)	6	NC
7	l219_LAN (-)	8	BUZZER
9	l210_LAN (-)	10	Ground
11	I210_LAN (+)	12	Power Button Signal
13	HDD_LED (+)	14	Reset Signal
15	HDD_LED (-)	16	Ground

J11: GPIO Pin Header

10	1	73	0	75
140	0			
	0			
	\sim	1	2	\sim

PIN No.	Description	PIN No.	Description
1	GPIO_0	2	GPIO_4
3	GPIO_1	4	GPIO_5
5	GPIO_2	6	GPIO_6
7	GPIO_3	8	GPIO_7
9	Ground	10	VCC

Copyright © Portwell 2016

J12: ATX 8 Pin Connector(For CPU Power)

0	10	
0		5-1
\bigcirc		
]()

PIN No.	Description	PIN No.	Description
1	Ground	5	+12V
2	Ground	6	+12V
3	Ground	7	+12V
4	Ground	8	+12V

J18/J19/J22/J23: COM1/COM2/COM3/COM4 Pin Header

	Z			10
[0.0	0	0	0
	0			
	_			

PIN No.	Description	PIN No.	Description
1	DCD#	2	RXD#
3	TXD#	4	DTR#
5	Ground	6	DSR#
7	RTS#	8	CTS#
9	RI#	10	NC

J27: Audio Pin Header



PIN No.	Description	PIN No.	Description
1	MIC_IN	2	Ground
3	LINE_IN_L	4	Ground
5	LINE_IN_R	6	Ground
7	AUDIO_OUT_L	8	Ground
9	AUDIO_OUT_R	10	Ground

4 Signal Descriptions

4.1 Watch Dog Signal

#Define WDTCFG 0x06 //WDT Timer Counter Register#Define WDTMIN 0x07 //WDT Timer Counter Register (Minute)#Define WDTSEC 0x08 //WDT Timer Counter Register (Second)

VOID Write_EC_SRAM(UINT8 Offset,UINT8 Value){

```
loWrite8(0xE300+Offset,Value);
```

```
Byte Read_EC_SRAM(UINT8 Offset){
loRead8(0xE300+offset,Value);
return Value;
}
```

```
void WDT()
```

```
{
```

}

// Enable WDT 30sec

Write_EC_SRAM(WDTSEC,30); Write_EC_SRAM(WDTCFG,0x01);//Bit0: WDT Enable, BIT1: 0:Second Mode

// Enable WDT 5min
Write_EC_SRAM(WDTSEC,5);
Write_EC_SRAM(WDTCFG,0x03);//Bit0: WDT Enable, BIT1: 1:Minute Mode

// Enable WDT 10min, 20sec
Write_EC_SRAM(WDTSEC,20);
Write_EC_SRAM(WDTSEC,10);
Write_EC_SRAM(WDTCFG,0x03);//Bit0: WDT Enable, BIT1: 1:Minute Mode

4.2 GPIO Signal

```
#Define GPCR 0x2B//GPIO Counter Register, Bit7 = GPIO7, Bit6 = GPIO6, ..., 0: Output; 1: Input
#Define GPDR 0x2C//GPIO Data Register, Bit7 = GPIO7, Bit6 = GPIO6, ..., 0: Low; 1: High
```

```
VOID Write_EC_SRAM(UINT8 Offset,UINT8 Value){
 IoWrite8(0xE300+Offset,Value);
Byte Read_EC_SRAM(UINT8 Offset){
 loRead8(0xE300+offset,Value);
 return Value;
void GPIO()
{
    int Temp;
    // Get GPIO data
     Temp = Read_EC_SRAM(GPDR);
    // Set GPIO7 High
     Temp |= 0x80;
     Write_EC_SRAM(GPDR,Temp);
                                             //Bit7: GPIO7 status, 0: Low 1: High
```

Copyright © Portwell 2016

5 System Resources

5.1 Intel® Skylake-S PCH

Intel® Q170 Chipset (Intel® GL82Q170 PCH) Intel® C236 Chipset (Intel® GL82C236 PCH)

5.2 Main Memory

ROBO-8113VG2AR provides 2 x 288-pin Long-DIMM sockets which supports DDR4 ECC/non-ECC memory. The maximum memory can be up to 32GB. Memory clock and related settings can be detected by BIOS via SPD interface.

Watch out the contact and lock integrity of memory module with socket, it will impact on the system reliability. Follow normal procedures to install memory module into memory socket. Before locking, make sure that all modules have been fully inserted into the card slots.

5.3 Installing the Single Board Computer

To install your ROBO-8113VG2AR into standard chassis or proprietary environment, please perform the following:

Step 1 : Check all jumpers setting on proper position

Step 2 : Install and configure CPU, CPU cooling and memory module on right position

Step 3 : Place ROBO-8113VG2AR into the dedicated position in the system

Step 4 : Attach cables to existing peripheral devices and secure it

WARNING

Please ensure that mother board is properly inserted and fixed by mechanism.

Note:

Please refer to section 6.3.1 to 6.3.4 to install INF/Graphic/LAN

5.3.1 Chipset Component Driver

ROBO-8113VG2AR is based on Intel® Q170/C236 chipset and desktop/workstation processors including Xeon E3-1200v5/Core[™] i7 / i5 / i3 sku . It's a new chipset that some old operating systems might not be able to recognize. To overcome this compatibility issue, for Windows Operating Systems such as Windows 8, please install its INF before any of other Drivers are installed. You can find very easily this chipset component driver in ROBO-8113VG2AR CD-title

5.3.2 Intel® HD Graphics 530

ROBO-8113VG2AR has integrated Intel® HD Graphics 530 which supports DirectX 12 \ OpenCL 2.0 \ OpenGL 4.4. It is the most advanced design to gain an outstanding graphic performance. ROBO-8113VG2AR supports VGA+DVI-D by DVI-I connector on bracket, and on board HDMI display output. This combination makes ROBO-8113VG2AR an excellent performance hardware.

Drivers Support

Please find the Graphic driver in the ROBO-8113VG2AR CD-title. The driver supports Windows 8.

- 5.3.3 Intel LAN I210AT/I219LM Gigabit Ethernet Controller
- Intel I210AT Gigabit Ethernet controller and 1x RJ45 connectors on bracket
- Intel I219LM Gigabit Ethernet controller and 1x RJ45 connectors on bracket

Drivers Support

Please find Intel I210AT/I219LM LAN driver in /Ethernet directory of ROBO-8113VG2AR CD-title. The driver supports Windows 8.

6 BIOS Setup Items

6.1 Introduction

The following section describes the BIOS setup program. The BIOS setup program can be used to view and change the BIOS settings for the module. Only experienced users should change the default BIOS settings.

6.2 BIOS Setup

Power on the computer and the system will start POST (Power on Self Test) process. When the message below appears on the screen, press <Delete> or <ESC> key will enter BIOS setup screen.

Press<Delete> or <ESC> to enter SETUP

If the message disappears before responding and still wish to enter Setup, please restart the system by turning it OFF and On or pressing the RESET button. It can be also restarted by pressing <Ctrl>, <Alt>, and <Delete> keys on keyboard simultaneously.

Press <F1> to Run General Help or Resume

The BIOS setup program provides a General Help screen. The menu can be easily called up from any menu by pressing <F1>. The Help screen lists all the possible keys to use and the selections for the highlighted item. Press <Esc> to exit the Help Screen.

1144	: Move
Enter	: Select
+/-	: Value
ESC	: Exit
F1	: General Help
F2	: Previous Values
F3	: Optimized Defaults
F4	: Save & Exit Setup
<k></k>	: Scroll help area upwards
<m></m>	: Scroll help area downwards
6.2.1 Main

Use this menu for basic system configurations, such as time, date etc.

Aptio Setup Utility – Copyright (C) 2016 American Megatrends, Inc.		
Main Configuration Security Boo	t Save & Exit	
Project Name BIOS Version & Build Date EC Version & Build Date	ROBO-8113VG2AR-Q170 R1.00.E0 (01/28/2016 18:13:25) R04.E01	
Processor Information Name Brand String	SkyLake DT Intel(R) Core(TM) i7–6700TE CPU @ 2.40GHz	
Total Memory Memory Frequency	16384 MB 2133 MHz	
PCH Information Name PCH SKU Stepping LAN PHY Revision	SKL PCH-H PCH-H Desktop Q170 SKU 31/D1 B2	
ME FW Version ME Firmware Mode ME Firmware SKU	0.0.0.0 Normal Mode Unidentified	
System Date System Time	[Tue 05/03/2016] [09:31:59]	
Access Level	Administrator	
Versio	n 2.17.1255. Copyright (C) 2016 American Megatrends, Inc.	

ROBO-8113VG2AR

Feature	Description	Options
System Date	The date format is <day>, <month> <date> <year>. Use $[+]$ or $[-]$ to configure system Date.</year></date></month></day>	
System Time	The time format is <hour> <minute> <second>. Use $[+]$ or $[-]$ to configure system Time.</second></minute></hour>	

6.2.2 Configuration

Use this menu to set up the items of special enhanced features

Aptio Setup Utility – Copyright (C) 2016 American Megatrends, Inc. Main <mark>Configuration</mark> Security Boot Save & Exit			
 CPU Configuration Chipset Configuration LAN Configuration Graphics Configuration PCI/PCIE Configuration SATA Configuration USB Configuration Power Control Configuration TPM Configuration Super IO Configuration H/W Monitor Serial Port Console Redirection 	CPU Configuration Parameters		
	<pre> ++: Select Screen 14: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</pre>		
Version 2.17.1255. Copyright (C) 2016 American Megatre	nds, Inc.		

CPU Configuration

CPU Configuration Parameters

Apt Configuration	io Setup Utility – Copyright	(C) 2016 American Megatrends, Inc.
CPU Configuration		▲ Enabled for Windows XP and Linux (OS
Intel(R) Core(TM) i7–6700TE CPU	0 2.40GHz	Technology) and Disabled for other OS
CPU Signature	506E3	(OS not optimized for Hyper-Threading
Max CPU Speed	2400 MHz	Technology). When Disabled only one
Min CPU Speed	800 MHz	thread per enabled core is enabled.
CPU Speed	2400 MHz	
Processor Cores	4	
Hyper Threading Technology	Supported	
Intel VT–x Technology	Supported	
Intel SMX Technology	Supported	
64-bit	Supported	
EIST Technology	Supported	
CPU C3 state	Supported	
CPU C6 state	Supported	
CPU C7 State	Supported	
l 1 Data Carbe	32 kB x 4	
L1 Code Cache	32 kB x 4	++: Select Screen
L2 Cache	256 kB x 4	11: Select Item
L3 Cache	8 MB	Enter: Select
L4 Cache	Not Present	+/-: Change Opt.
		F1: General Help
Hyper-threading	[Enabled]	F2: Previous Values
Active Processor Cores	[A11]	F3: Optimized Defaults
Intel Virtualization Technology	[Enabled]	F4: Save & Exit
Intel(R) SpeedStep(tm)	[Enabled]	ESC: Exit
Turbo Mode	[Enabled]	
CPU C states	[Enabled]	
Enhanced C-states	[Enabled]	
C-State Auto Demotion	[C1 and C3]	an a
C-State Un-demotion	[C1 and C3]	
Package C state demotion	[Enabled]	
Package C state undemotion	[Enabled]	
Ve	rsion 2.17.1255. Copyright (C) 2016 American Megatrends, Inc. B4

Feature	Description	Options
	Enabled for Windows XP and Linux (OS optimized for Hyper-threading Technology) and	
Hyper-threading	Disabled for other OS (OS not optimized for Hyper-threading Technology). When Disabled only	★Enabled, Disabled
	one thread per enabled core is enabled.	
Active Processor Cores	Number of cores to enable in each processor package.	★All, 1, 2, 3
Intel Virtualization Technology	When enabled, a VMM can utilize the additional hardware capabilities provided by Vanderpool	+Enabled Disabled
inter virtualization recimology	Technology.	
Intel® Speed Step™	Allows more than two frequency ranges to be supported.	★Enabled, Disabled
Turbo Mode	Turbo Mode.	★Enabled, Disabled
Configurable TDP Root Mode	Configurable TDP Mode as Nominal /Up/ Down/ Deactivate TDP selection. Deactivate option	★Nominal, Down, Up,
Configurable TDF Boot Mode	will set MSR to Nominal and MMIO to Zero.	Deactivate
CPU C states	Enable or disable CPU C states	+Disabled Enabled
(Enabled)		★ Disableu, Ellableu
Enhanced C states	Enable/Disable C1E. When enabled, CPU will switch to minimum speed when all cores enter	+ Enchlad Dischlad
Ennanced C-states	C-State.	
C-State Auto Demotion	Configure C State Auto Domotion	★C1 and C3, Disabled,
		C1, C3,
C State Un domotion	Configure C. State Lin dometion	★C1 and C3, Disabled,
C-State Un-demotion		C1, C3,

Package C State demotion	Enable Package C state demotion.	★Enabled, Disabled
Package C state undemotion	Enable Package C state undemotion	★Enabled, Disabled
C State Pre-Wake	Disable – Sets bit 30 of POWER_CTL MSR(0x1FC) to 1 to disable the C State Pre-Wake	★Enabled, Disabled
Package C State limit	Daskaga C Stata limit	★AUTO, C0/C1, C2, C3,
		C6, C7, C7s, C8
CFG lock	Configure MSR 0xE2 [15], CFG lock bit.	★Enabled, Disabled

Chipset Configuration

Aptic	o Setup Utility – Copyright (C)	2016 American Megatrends, Inc.
Configuration		VT-d canabilitu
Total Memory DIMM#0 DIMM#1 /T-d Above 4GB MMIO BIOS assignment	16384 MB 8192 MB 8192 MB [Enabled] [Disabled]	
HD Audio Port 80h Redirection	[Enabled] [LPC Bus]	
AMT Configuration		
		++: Select Screen 11: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit

Feature	Description	Options	
VT-d	VT-d capability	★Enabled, Disabled	
Above 4GB MMIO BIOS assignment	Enable/Disable above 4GB Memory Mapped IO BIOS assignment. This is disabled	★Disabled, Enabled	
	automatically when Aperture Size is set to 2048MB.		
	Control Detect of the HD-Audio device.		
HD Audio	Disabled = HAD will be unconditionally disabled	★Enabled, Disabled	
	Enabled = HAD will be unconditionally Enabled		
Port 80h Redirection	Control where the port 80h cycles are sent.	★LPC Bus, PCIE Bus	

AMT Configuration

Configure Active Management Technology Parameters

Configuration	Aptio Setup Utility – Copyright (C) 2016 American Megatrends, Inc. Configuration		
Intel AMT Un-Configure ME	[Disabled] [Disabled]	Enable/Disable Intel (R) Active Management Technology BIOS Extension. Note : iAMT H/W is always enabled. This option just controls the BIOS extension execution. If enabled, this requires additional firmware in the SPI device	
		<pre> ++: Select Screen 14: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</pre>	
	Version 2.17.1255. Copyright (C) 2	016 American Megatrends, Inc.	

Feature	Description	Options
	Enable/Disable Intel	
Intel AMT	Note: iAMT H/W is always enabled.	A Dischlad Enchlad
(Enabled)	This option just controls the BIOS extension execution. If enabled, this requires	
	additional firmware in the SPI device	
Un-Configure ME	OEMFlag Bit 15: Un-Configure ME without password.	★Disabled, Enabled

LAN Configuration Configuration on Board LAN device.

Aptio Se Configuration	tup Utility – Copyright (C) 2016 American Mega	atrends, Inc.
LAN Configuration		Enable or disable onboard NIC.
Intel Ethernet Controller I219–LM LAN MAC Address PCH LAN Controller Wake on LAN Launch Legacy PXE Rom Intel Ethernet Controller WGI210AT	00-90-FB-58-71-07 [Enabled] [Enabled] [Disable]	
LAN MAC Address Intel I210 LAN Controller Launch Legacy PXE Rom	00-90-FB-12-34-56 [Enabled] [Disable]	
		<pre> ++: Select Screen 14: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit </pre>
Version	1 2.17.1255. Copyright (C) 2016 American Megatr	rends, Inc.

Feature	Description	Options
PCH LAN Controller	Enable or disable onboard NIC	★Enabled, Disabled
Wake on LAN	Enable or disable integrated LAN to wake the system. (The Wake On LAN cannot be disabled if ME is on at Sx state.)	★Enabled, Disabled
Launch Legacy PXE Rom	Launch Legacy PXE Rom. [Disable] Not launch Rom, [Enable] Force launch Rom, [Auto] Auto detect LAN Cable state to Enable/Disable Rom initial.	★Disable, Enable, Auto
Intel I210 LAN Controller	Intel I210 LAN Controller.	Disabled, ★Enabled
Launch Legacy PXE Rom	Launch Legacy PXE Rom. [Disable] Not launch Rom, [Enable] Force launch Rom, [Auto] Auto detect LAN Cable state to Enable/Disable Rom initial.	★Disable, Enable, Auto

Graphics Configuration Configuration Graphics Settings

Graphics Configuration Select Secondary Display Device Primary PEG [Auto] Primary PEG [Auto] Internal Graphics [Auto] Internal Graphics [Auto] Aperture Size [256MB] DVMT Pre-Allocated [32M] DVMT Total Gfx Mem [256M] Primary IGFX Boot Display [HOMI] Secondary IGFX Boot Display [Disabled]	Configuration	Aptio Setup Utility – Copyright (C) 2016	American Megatrends, Inc.
Primary Display [Auto] Primary PEG [Auto] Internal Graphics [Auto] Internal Graphics [Auto] GTT Size [GH8] Aperture Size [256M] DVMT Fore-Allocated [32M] DVMT Total Gfx Mem [256M] Primary IGFX Boot Display [H0MI] Secondary IGFX Boot Display [Disabled] **: Select Screen 11: Select Item Enter: Select F1: General Help F2: Previous Values F3: Gove a Exit E0: Exit	Graphics Configuration		Select Secondary Display Device
++: Select Screen 14: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit	Primary Display Primary PEG Primary PCIE Internal Graphics GTT Size Aperture Size DVMT Pre-Allocated DVMT Total Gfx Mem Primary IGFX Boot Display Secondary IGFX Boot Display	[Auto] [Auto] [Auto] [Auto] [8MB] [256MB] [32M] [256M] [HDMI] [Disabled]	
			<pre> ++: Select Screen 14: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</pre>

Feature	Description	Options
Primary Display	Select which of IGFX/PEG/PCI Graphics device should be Primary Display Or select SG for Switchable Gfx.	★Auto, IGFX, PEG, PCIE
Primary PEG	Select Auto/PEG11/ PEG12 Graphics device should be Primary PEG.	★Auto, PEG11, PEG12
Primary PCIE	Select Auto/PCIE9 of D29: F1, Graphics device should be Primary PCIE.	★Auto, PCIE9
Internal Graphics	Keep IGFX enable based on the setup options.	★Auto, Disabled, Enabled
GTT Size	Select the GTT Size	★8MB, 2MB, 4MB
Aperture Size	Select the Aperture Size Note: Above 4GB MMIO BIOS assignment is automatically enabled when selecting 2048MB aperture. To use this feature, please disable CSM Support.	★256MB, 128MB, 512MB, 1024MB,2048MB,4096MB
DVMT Pre-Allocated	Select DVMT 5.0 Pre-Allocated (Fixed) Graphics Memory size used by the Internal Graphics Device.	 ★32M,64M,96M,128M, 160M,192M,224M,256M,288M ,320M,352M,384M,416M,448 M,480M,512M, 1024M,1536M,2048M, 4M, 8M,12M,16M,20M,24M,28M,3 2M,/F7,36M,40M,44M,48M,52 M,56M,60M

DVMT Total Gfx Mem	Select DVMT5.0 Total Graphic Memory size used by the Internal Graphics Device	★256M, 128M, MAX
Primary IGFX Boot Display	Select the Video Device which will be activated during POST. This has no effect if external graphics present. Secondary boot display selection will appear based on your selection. VGA modes will be supported only on primary display.	★VBIOS Default, HDMI, DVI, VGA
Secondary IGFX Boot Display	Select Secondary Display Device.	★Disabled, HDMI, DVI, VGA

PCI/PCIE Configuration

PCI, PCI-X and PCI Express Settings.

Aptio Setup Utility – Copyright (C) 2016 American Megatrends, Inc. Configuration				
PCI/PCIE Configuration		Enable or disable PCI Express Clock Gating for each root port.		
PCI Express Clock Gating DMI Link ASPM Control	[Enabled] [Enabled]			
 PCIE Port 5 is assigned to LAN PCIE Port 6 is assigned to LAN PCI Express Root Port 7 PCI Express Root Port 9 PCI Express Root Port 10 PCI Express Root Port 11 PCI Express Root Port 12 				
PCIE Port PCIE Port Current Config Link Width	Current Link Speed =============			
P1(D27/F0) ×1 P2(D27/F1) ×1 P3(D27/F2) ×1 P4(D27/F3) ×1 P5(D28/F0) ×1 P6(D28/F1) ×1 P6(D28/F2) ×1 P7(D28/F2) ×1 P8(D28/F3) ×1 P10(D28/F3) ×1 P10(D28/F6) P11(D28/F6) P12(D28/F7) P13(D29/F0) ×1 ×1 P14(D29/F1) ×1 P15(D29/F2) ×1 P16(D29/F3) ×1 P17(D29/F4) ×1	 GEN1 (2.5GT/s) GEN1 (2.5GT/s) 	<pre> ++: Select Screen 14: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit </pre>		
. Version	2.17.1255. Copyright (C) 2016 American Megat	rends, Inc.		

Feature	Description	Options
PCI Express Clock Gating	Enable or disable PCI Express Clock Gating for each root port.	Disabled ★Enabled
DMI Link ASPM Control	Enable/Disable the control of Active State Power Management on SA side of the DMI Link.	Disabled ★Enabled

PCI Express Root Port7, Port9, Port10, Port11, Port12

PCI Express Root Port7, Port9, Port10, Port11, Port12

Configuration	Aptio Setup Utility – Copyright (C)	2016 American Megatrends, Inc.
PCI Express Root Port 7 ASPM Support PCIe Speed	[Enabled] [Disabled] [Auto]	Control the PCI Express Root Port. ++: Select Screen 14: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
	Version 2.17.1255. Copyright (C) 2	016 American Megatrends, Inc.

Feature	Description	Options
PCI Express Root Port7, Port9, Port10, Port11, Port12	Control the PCI Express Root Port.	★Enabled, Disabled
	Set the ASPM Level:	
ASPM Support	Force L0s – Force all links to L0s State	★Disabled, L0s, L1, L0sL1,
	AUTO-BIOS auto configure	Auto
	DISABLE – Disables ASPM	
PCIe Speed	Select PCI Express port speed	★Auto, Gen1, Gen2, Gen3

TA Device Options Settings		
Configuration	Aptio Setup Utility – Copyright (C) 20	16 American Megatrends, Inc.
SATA Configuration		Determines how SATA controller(s)
SATA Controller(s)	[Enabled]	operate.
SATA Mode Selection	[RAID]	
Alternate ID	[Disabled]	
Serial ATA Port O	Empty	
Software Preserve	Unknown	
Port 0	[Enabled]	
Hot Plug	[Disabled]	
External SATA	[Disabled]	
SATA Device Type	[Hard Disk Drive]	
Serial ATA Port 1	Empty	
Software Preserve	Unknown	
Port 1	[Enabled]	
Hot Plug	[Disabled]	
External SATA	[Disabled]	
SATA Device Type	[Hard Disk Drive]	
Serial ATA Port 2	Empty	++: Select Screen
Software Preserve	Unknown	t↓: Select Item
Port 2	[Enabled]	Enter: Select
Hot Plug	[Disabled]	+/-: Change Opt.
External SATA	[Disabled]	F1: General Help
SATA Device Type	[Hard Disk Drive]	F2: Previous Values
Serial ATA Port 3	Empty	F3: Optimized Defaults
Software Preserve	Unknown	F4: Save & Exit
Port 3	[Enabled]	ESC: Exit
Hot Plug	[Disabled]	
External SATA	[Disabled]	
SATA Device Type	[Hard Disk Drive]	
Serial AlA Port 4	Empty	
Software Preserve	Unknown	
Port 4	[Enabled]	
HOT PIUg	[U1sabled]	

Version 2.17.1255. Copyright (C) 2016 American Megatrends, Inc.

Copyright © Portwell 2016

Feature	Description	Options
SATA Controller(s)	Enable or disable SATA Device.	★Enabled, Disabled
SATA Mode Selection	Determines how SATA controller(s) operate.	★AHCI, RAID
Alternate ID	Report alternate Device ID	★Disabled, Enabled
Port 0 – Port 5	Enable or Disable SATA Port	★Enabled, Disabled
Hot Plug	Designates this port as Hot Pluggable	★Disabled, Enabled
External SATA	External SATA Support.	★Disabled, Enabled
SATA Device Type	Indentify the SATA part is connected to Solid State Drive or Hard Diek Drive	★hard Disk Drive, Solid State
		Drive

USB Configuration

USB Configuration Parameters.		
Aptio Configuration	Setup Utility – Copyright (C) 2016 Americ	can Megatrends, Inc.
Configuration USB Configuration USB Devices: 1 Drive, 1 Keyboard Legacy USB Support XHCI Legacy Support XHCI Hand-off USB Mass Storage Driver Support ► PCH USB Configuration Mass Storage Devices: UFD 3.0 Silicon-Power16G1.00	[Enabled] [Enabled] [Disabled] [Enabled] [Auto] UFD 3.0 Silicon-Power16G1.00 Auto Floppy Forced FDD	Mass storage device emulation type. 'AUTO' enumerates devices according to their media format. Optical drives are emulated as 'CDROM', drives with no media will be emulated according to a drive type.
	Hard Disk CD-ROM	<pre>++: Select Screen tl: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</pre>
Vers1	on 2.17.1255. copyrignτ (c) 2016 American	n Megatrends, Inc.

Feature	Description	Options	
	Enables Legacy USB support. AUTO option disables legacy support if no USB		
Legacy USB Support	Devices are connected. DISBLE option will keep USB devices available only for EFI	★Enabled, Disabled, Auto	
	applications.		
XHCI Legacy Support	Enable/Disable XHCI Controller Legacy support.	★Enable, Disabled	
XHCI Hand-off	This is workaround for OSes without XHCI hand-off support. The XHCI ownership change	+Dischlad Enchlad	
	should be claimed by XHCI driver.		
USB Mass Storage Driver	Enable/Disable USB Mass Storage Driver Support	+Enable Disabled	
Support			
Mass Storage Devices	Mass Storage device emulation type. 'AUTO' enumerates devices according to their media	+Auto Elonny Earoad EDD	
	format. Optical drives are emulated as 'CDROM', drives with no media will be emulated	Hard Dick CD POM	
	according to a drive type.		

PCH USB Configuration

PCH USB Configurtion

Aptio Se Configuration	tup Utility – Copyright (C) 2016 American Mega 	trends, Inc.
USB Configuration USB Precondition	[Disabled]	Precondition work on USB host controller and root ports for faster enumeration.
xDCI Support	(Disabled)	
USB Port Disable Override USB HS Physical Connector #0 USB HS Physical Connector #1 USB HS Physical Connector #2 USB HS Physical Connector #3 USB HS Physical Connector #4 USB HS Physical Connector #6 USB HS Physical Connector #7 USB HS Physical Connector #7 USB HS Physical Connector #9 USB HS Physical Connector #10 USB HS Physical Connector #11 USB HS Physical Connector #12 USB HS Physical Connector #12 USB HS Physical Connector #13	[Select Per-Pin] [Enabled] [Enabled] [Enabled] [Enabled] [Enabled] [Enabled] [Enabled] [Enabled] [Enabled] [Enabled] [Enabled] [Enabled] [Enabled]	<pre>**: Select Screen f4: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</pre>
Version	2.17.1255. Copyright (C) 2016 American Megatre	ends, Inc.

Feature	Description	Options
USB Precondition	Precondition work on USB host controller and root ports for faster Enumeration.	★Disabled, Enabled
xDCI Support	Enable/Disable xDCI (USB OTG Device).	★Disabled, Enabled
USB Port Disable Override	Selectively Enable/Disable the corresponding USB port from reporting a Device	★Disabled, Select Per-Pin
(Select Per-Pin)	Connection to the controller.	
USB HS Physical Connector #0 - #13	Enable/Disable USB Port.	★Enabled, Disabled

Power Control Configuration

Configuration	Aptio Setup Utility – Copyright (C) 2016 A	American Megatrends, Inc.
cower Control Configuration Chable Hibernation CPI Sleep State Sestore AC Power Loss	[Enabled] [S3 (Suspend to RAM)] [Power Off] [Enabled]	Enable or disable System wake on alarn event. [Enabled], system will wake on the Hour:Min:Sec specified. [Disabled] Turn off RTC Wakeup.
gstem rime ake up day ake up Time(HH:mm:ss)	[02:37:43] 0 [00:00:00]	
		<pre>++: Select Screen fl: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</pre>

Feature	Description	Options
Enable Hibernation	Enables or Disables System ability to Hibernate (OS/S4 Sleep State). This option	+ Enchlad Dischlad
	may be not effective with some OS.	
ACRI Sloon State	Select the highest ACPI sleep state the system will enter when the SUSPEND	★S3 (Suspend to RAM), Suspend
ACFT Sleep State	button is pressed.	Disabled
	Specify what state to go to when power is re-applied after a power failure (G3	+ Power Off Power On
Restore AC Power Loss	state)	*Power OII , Power OII
DTC Wake up	Enable or disable System wake on alarm event.	
(Enchlod)	[Enabled], system will wake up the Hour: Min: Sec specified.	★Disabled, Enabled
	[Disabled] Turn off RTC Wakeup.	
Wake up day	Select 0 for daily system wake up 1-31 for which day of the month that you would	1 31
	like the system to wake up	1-51
Wake up Time(HH: mm: ss)	Use [Enter], [TAB] to select field, HH: 0-23, mm: 0-59, ss: 0-59	HH: 0-23, mm: 0-59, ss: 0-59

<u>M Configuration</u> sted Computing settings		
Configuration	Aptio Setup Utility – Copyright (C)	2016 American Megatrends, Inc.
TPM Configuration		TPM 1.2 will restrict support to TPM 1.2 devices, TPM 2.0 will restrict
Security Device Support Device Select	[Enable] [Auto]	support to TPM 2.0 devices, Auto will support both with the default set to TPM 2.0 devices if not found, TPM 1.2 devices will be enumerated
urrent Status Information NO Security Device Found		
		fl: Select Screen fl: Select Item Enter: Select +/-: Change Ont
		F1: General Help F2: Previous Values F3: Ontimized Defaults
		F4: Save & Exit ESC: Exit
	Version 2 17 1255 Conuright (C) 2	016 American Megatrends Inc

Feature	Description	Options
Security Device Support	Enables or Disables BIOS support for security device. O.S. will not show Security	A Dischlad Enchlad
(Enabled)	Device. TCG EFI protocol and INT1A Interface will not be available.	★Disabled, Enabled
	TPM 1.2 will restrict support to TPM 1.2 devices, TPM 2.0 will restrict support to TPM 2.0	
Device Select	devices, Auto will support both with the default set to TPM 2.0 devices if not found, TPM	★Auto, TPM 1.2, TPM 2.0
	1.2 devices will be enumerated.	

Super IO Configuration

5	System Super IO Chip Parameters.			
	Configuration	Aptio Setup Utility – Copyright (C)	2016 American Megatrends, Inc.	
Γ	Super IO Configuration		Enable/Disable Watch Dog Timer	
	Serial Port 1 Configuration Serial Port 2 Configuration Serial Port 3 Configuration Serial Port 4 Configuration			
	Watch Dog Timer Timer Unit Timer value	[Enabled] [Second] 20		
			<pre> ++: Select Screen 14: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</pre>	
L		Version 2.17.1255. Copyright (C) 20	16 American Megatrends, Inc.	

Feature	Description	Options
Watch Dog Timer	Enchle/Dischle Wetch Deg Timer	A Disphied Exchine
(Enabled)		★DISADIED, ENADIED
Timer Unit	Select Timer count unit of WDT	★Second, Minute
Timer value	Set WDT Timer value	★20

Serial Port 1 Configuration Set Parameters of Serial Port 1 ((COM 1)	
Main	Aptio Setup Utility – Copyright (C) 2016	American Megatrends, Inc.
Serial Port 1 Configuration		Select an optimal settings for Super IO
<mark>Serial Port</mark> Device Settings	[Enabled] IO=3F8h; IRQ=4;	Device
Change Settings	[IO=3F8h; IRQ=4;]	
		++: Select Screen ↑↓: Select Item Enter: Select
		+/-: Change Opt. F1: General Help
		F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit
	Vencion 2 17 1255 Conunight (C) 2016 4	menican Meratopada Tac

Feature	Description	Options
Serial Port	Enable or Disable Serial Port (COM)	★Enabled, Disabled
		★IO=3F8h; IRQ=4, Auto,
		IO=240h; IRQ=3,4,5,6,7,10,11,12
Change Settings	Select an optimal settings for Super IO Device	IO=248h; IRQ=3,4,5,6,7,10,11,12
		IO=250h; IRQ=3,4,5,6,7,10,11,12
		IO=258h; IRQ=3,4,5,6,7,10,11,12

Serial Port 2 Configuration Set Parameters of Serial Port 2 (COM 2)

Apti Main	o Setup Utility – Copyright (C) 2016 American Mega	atrends, Inc.
Serial Port 2 Configuration		Enable or Disable Serial Port (COM)
Serial Port Device Settings	[Enabled] IO=2F8h; IRQ=3;	
Change Settings	[I0=2F8h; IRQ=3;]	
		<pre>++: Select Screen fl: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</pre>
Ver	sion 2.17.1255. Copyright (C) 2016 American Megatr	rends, Inc.

Feature	Description	Options
Serial Port	Enable or Disable Serial Port (COM)	Disabled, ★Enabled
Change Settings		★IO=2F8h; IRQ=3; Auto,
	Select an optimal settings for Super IO Device.	IO=240h; IRQ=3,4,5,6,7,10,11,12
		IO=248h; IRQ=3,4,5,6,7,10,11,12
		IO=250h; IRQ=3,4,5,6,7,10,11,12
		IO=258h; IRQ=3,4,5,6,7,10,11,12

Serial Port 3 Configuration

Set Parameters of Serial Port 3 (COM 3)



Copyright © Portwell 2016
Feature	Description	Options
Serial Port	Enable or Disable Serial Port (COM)	★Enabled, Disabled
		★ RS-232,
RS-232/422/485 Control Option	Serial Port 3 RS-232/422/485 Control Option	RS-485 HALF DUPLEX
		RS-485/422 FULL DUPLEX
		★ IO=240h; IRQ=11, Auto,
Change Settings		IO=240h; IRQ=3,4,5,6,7,10,11,12
	Select an optimal setting for Super IO Device.	IO=248h; IRQ=3,4,5,6,7,10,11,12
		IO=250h; IRQ=3,4,5,6,7,10,11,12
		IO=258h; IRQ=3,4,5,6,7,10,11,12

Serial Port 4 Configuration Set Parameters of Serial Port 4 (COM 4)

Apt Main	Aptio Setup Utility – Copyright (C) 2016 American Megatrends, Inc.	
Serial Port 4 Configuration		Enable or Disable Serial Port (COM)
Serial Port Device Settings RS-232/422/485 Control Option	[Enabled] IO=2E8h; IRQ=10; [RS-232]	
Change Settings	[IO=2E8h; IRQ=10;]	
		<pre>++: Select Screen f1: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</pre>
Ve	rsion 2.17.1255. Copyright (C) 2016 America	an Megatrends, Inc.

Feature	Description	Options
Serial Port	Enable or Disable Serial Port (COM)	Disabled, ★Enabled
RS-232/422/485 Control Option		★ RS-232,
	Serial Port 4 RS-232/422/485 Control Option	RS-485 HALF DUPLEX
		RS-485/422 FULL DUPLEX
Change Settings		★IO=248h; IRQ=11, Auto,
		IO=240h; IRQ=3,4,5,6,7,10,11,12;
	Select an optimal settings for super IO Device	IO=248h; IRQ=3,4,5,6,7,10,11,12;
		IO=250h; IRQ=3,4,5,6,7,10,11,12;
		IO=258h; IRQ=3,4,5,6,7,10,11,12;

Configuration	Aptio Setup Utility - Copyright (C) 24	Die Hmerican Megatrenos, Inc.
Pc Health Status Smart CPU Fan Function CPU Start Target Temp CPU Full Target Temp Smart System Fan Function System Start Target Temp System Full Target Temp CPU temperature System temperature CPU Fan Speed System Fan Speed Acore	[Enabled] 30 50 [Enabled] 30 50 : +31 % : +33 % : 10317 RPM : 8422 RPM : +0.996 V : +3.444 V	Enable or Disable Smart CPU Fan.
-12V /DIMM	: +12.295 V : +1.218 V	<pre>→+: Select Screen 1↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</pre>

Feature	Description	Options
Smart CPU Fan Function	Enable or Disable Smart CDLL Ean	
(Enabled)		
CPU Start Target Temp	CPU Start Fan Target Temperature.	30
CPU Full Target Temp	CPU Full Fan Target Temperature.	50
Smart System Fan Function	Enable or Disable Smort System Fon	A Dischlad Enchlad
(Enabled)		
System Start Target Temp	System Start Fan Target Temperature.	30
System Full Target Temp	System Full Fan Target Temperature.	50

Serial Port Console Redirection

Aptio Se Configuration	tup Utility – Copyright (C) 2016 American Mega†	rends, Inc.
Serial Port Console Redirection		Console Redirection Enable or Disable.
COMO Console Redirection ▶ Console Redirection Settings	[Enabled]	
COM1(Pci Bus0,Dev0,Func0) (Disabled) Console Redirection	Port Is Disabled	
		<pre>++: Select Screen t1: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</pre>
Version	2.17.1255. Copyright (C) 2016 American Megatre	ends, Inc.

Feature	Description	Options
Console Redirection (COM 0-5) (Enabled)	Console Redirection Enable or Disable.	★Disabled, Enabled

COM 0 Serial Port Console Redirection

COM0 Serial Port Console Redirection

Aptio Setup Utility – Copyright (C) 2016 American Megatrends, Inc. <mark>Configuration</mark>		
Configuration Como Console Redirection Settings Terminal Type Bits per second Data Bits Parity Stop Bits Flow Control VT-UTF8 Combo Key Support Recorder Mode Resolution 100x31 Legacy OS Redirection Resolution Putty KeyPad Redirection After BIOS POST	Setup Utility – Copyright (C) 2016 American Mega [ANSI] [115200] [8] [None] [11] [None] [Enabled] [Disabled] [Disabled] [Disabled] [00x24] [VT100] [Always Enable]	<pre>trends, Inc. Emulation: ANSI: Extended ASCII char set. VT100: ASCII char set. VT100+: Extends VT100 to support color, function keys, etc. VT-UTF8: Uses UTF8 encoding to map Unicode chars onto 1 or more bytes. ++: Select Screen 14: Select Item Enter: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</pre>
Versi	on 2.17.1255. Copyright (C) 2016 American Megatr	ends, Inc.

Feature	Description	Options	
	Emulation: ANSI: Extended ASCII char set. VT100: ASCII char set. VT100+:		
Terminal Type	Extends VT100 to support color, function keys, etc. VT-UTF8: Uses UTF8	★ANSI, VT100, VT100+, VT-UTF8	
	encoding to map Unicode chars onto 1 or more bytes.		
Pite per second	Select Serial port transmission speed. The speed must be matched on other side.	+115200 0600 10200 28400 57600	
	Long or noisy lines may require lower speeds.	★ 115200, 9600, 19200, 38400, 57600	
Data bits	Data bits	★8, 7	
	A parity bit can be sent with the data bits to detect some transmission errors.		
	Even: parity bit is 0 if the num of 1's in the data bits is even.		
Parity	Odd: parity bit is 0 if num of 1's in the data bits is odd. Mark: parity bit is always 1.	★None, Even, Odd, Mark, Space	
	Space parity bit is always 0. Mark and Space Parity do not allow for error		
	detection. They can be used as an additional data bit.		
	Stop bits indicate the end of a serial data packet. (A start bit indicates the		
Stop Bits	beginning). The standard setting is 1 stop bit. Communication with slow devices	★ 1,2	
	may require more than 1 stop bit.		
Flow Control	Flow control can prevent data loss from buffer overflow. When sending data, if the		
	receiving buffers are full, a 'stop' signal can be sent to stop the data flow. Once	★None, Hardware RTS/CTS	
	the buffers are empty, a 'start' signal can be sent to re-start the flow. Hardware		
	flow control uses two wires to send start/stop signal.		

VT-UTFB Combo Key Support	Enable VT-UTF8 Combination Key Support for ANSI/VT100 terminals	★Enabled, Disabled
Recorder Mode	With this mode enabled only text will be sent. This is to capture Terminal data.	★Disabled, Enabled
Resolution 100x31	Enables or disables extended terminal resolution	★Disabled, Enabled
Legacy OS Redirection Resolution	On Legacy OS, the Number of Rows and Columns supports redirection	★80x24, 80x25
Putty KeyPad	Select FunctionKey and KeyPad on Putty	★VT100, LINUX,XTERMR6,
		SCO,ESCN,VT400
	The settings specify if BootLoader is selected then Legacy console redirection is	
Redirection After BIOS POST	disabled before booting to legacy OS. Default value is Always Enable with means	★Always Enable, BootLoader
	Legacy console Redirection is enabled for Legacy OS.	

6.2.3 Security

This section lets you set security passwords to control access to the system at boot time and/or when entering the BIOS setup program.

Aptio Se Main Configuration Security Boot	atup Utility − Copyright (C) 2016 American Mega : Save & Exit	atrends, Inc.
Password Description If ONLY the Administrator's password then this only limits access to Setu only asked for when entering Setup. If ONLY the User's password is set, is a power on password and must be a	l is set, p and is then this entered to	[Setup] check password when enter setup screen. [Power on] check password on every time system power on.
boot or enter Setup. In Setup the Us have Administrator rights. The password length must be in the following range: Minimum length	ser will 3	
Maximum length Password Check Mode	20 [Setup]	
Administrator Password User Password		++: Select Screen
HDD Security Configuration: 1st HDD Security: 2nd HDD Security: 3rd HDD Security: 4th HDD Security: 5th HDD Security: 6th HDD Security:	2 17 1255 Populaidht (P) 2016 American Marata	T1: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit

Feature	Description	Options	
Password Chack Mode	[Setup] check password when enter setup screen. [Power on] check password on	+Satur Dowar on	
Password Check Mode	every time system power on.	Setup, Power on	
Administrator Password	Set Administrator Password	★No default setting	
1st-6th HDD Security	HDD Security Configuration for selected drive.		

6.2.4 Boot

Use this menu to specify the priority of boot devices.

Main Configuration Security Boot	Aptio Setup Utility – Copyright (C) 2016 American Megatrends, Inc. Main Configuration Security <mark>Boot</mark> Save & Exit	
Boot Configuration Bootup NumLock State Option ROM Messages	[On] (Force BIOS)	This option controls Legacy/UEFI ROMs priority
Storage	(Legacy)	
Full screen Logo	(Disabled)	
Post Report Summary Screen	(Disabled) (Disabled)	
	[Legacy only]	
Boot Option Priorities Boot Option #1	[UFD 3.0 Silicon-Power16G1.00]	
Hard Drive BBS Priorities		<pre>**: Select Screen f1: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</pre>

Feature	Description	Options
Bootup NumLock State	Select the keyboard NumLock state	★On, Off
Option ROM Messages	Set display mode for Opion ROM	★Force BIOS, Keep Current
Storage	Controls the execution of the UEFI and Legacy Storage OpROM	★Legacy, Do not Launch, UEFI
Full screen Logo	Enables or disables Quiet Boot option and Full screen Logo.	★Disabled, Enabled
Post Report	Post Report Support Enabled/Disabled	★Disabled, Enabled
Summary Screen	Summary Screen Support Enabled/Disabled	★Disabled, Enabled
Boot option filter	This option controls Legacy/UEFI ROMs priority	★Legacy only, UEFI only
Hard Drive BBS Priorities	Set the order of the legacy devices in this group	

6.2.5 Save & Exit

Aptio Setup Utility – Copyright (C) 2016 American Mega Main Configuration Security Boot <mark>Save & Exit</mark>	trends, Inc.
Save Changes and Reset Discard Changes and Reset	Reset the system after saving the changes.
Default Options Restore Defaults	
Boot Override UFD 3.0 Silicon–Power16G1.00 Launch EFI Shell from filesystem device	
	<pre>++: Select Screen f↓: Select Item Enter: Select +/-: Change Opt. F1: General Help F2: Previous Values F3: Optimized Defaults F4: Save & Exit ESC: Exit</pre>
Version 2.17.1255, Copyright (C) 2016 American Megatry	ands. Inc.

Feature	Description	Options
Save Changes and Reset	Reset the system after saving the changes.	
Discard Changes and Reset	Reset system setup without saving any changes.	
Restore Defaults	Restore/Load Default values for all the setup options.	
UEFI: Built-in EFI Shell	Poset the system after saving the changes	
(Boot option filter: UEFI only)	Reset the system after saving the changes.	
l aunch EEI Sholl from filosystem device	Attempts to Launch EFI Shell application (Shell.efi) from one of the available	
auton Er i Shen nom mesystem device	filesystem devices.	

7 Troubleshooting

This chapter provides a few useful tips to quickly get ROBO-8113VG2AR running with success. As basic hardware installation has been addressed in Chapter 2, this chapter will focus on system integration issues, in terms of BIOS setting, and OS diagnostics.

7.1 Hardware Quick Installation

ATX Power Setting

Unlike other Single board computer, ROBO-8113VG2AR supports ATX only. Therefore, there is no other setting that really needs to be set up. However, there are only two connectors that must be connected—J12 ATX 8Pin Connector (4 pins CPU+12V main power connector) & 24 pins ATX Power Connector (On PICMG Backplane).



J12: ATX 8 Pin Connector(For CPU Power)

PIN No.	Description	PIN No.	Description
1	Ground	5	+12V
2	Ground	6	+12V
3	Ground	7	+12V
4	Ground	8	+12V

Serial ATA

Unlike IDE bus, each Serial ATA channel can only connect to one SATA hard disk at a time; there are total six connectors, SATA0~5 port. The installation of Serial ATA is simpler and easier than IDE, because SATA hard disk doesn't require setting up Master and Slave, which can reduce mistake of hardware installation. All you need to operate AHCI, RAID (0/1/5/10) application for system, please follow up setting guide in BIOS setup utility. ROBO-8113VG2AR can support six SATA interface (SATAIII, 6.0Gb/s) on board. It has four J2/J7/J15/J16 SATA ports on board; two SATA ports on PICMG Backplane. The SATA interface shall support both 1.5/3.0Gb & 6.0Gb operation per the SATA specification.



7.2 BIOS Setting

It is assumed that users have correctly adopted modules and connected all the devices cables required before turning on ATX power. CPU, CPU Fan, 288-Pin DDR4 memory, keyboard, mouse, SATA hard disk, DVI-I connector, device power cables, ATX accessories are good examples that deserve attention. With no assurance of properly and correctly accommodating these modules and devices, it is very possible to encounter system failures that result in malfunction of any device.

To make sure that you have a successful start with ROBO-8113VG2AR, it is recommended, when going with the boot-up sequence, to hit "delete" or "Esc" key and enter the BIOS setup menu to tune up a stable BIOS configuration so that you can wake up your system far well.

Loading the default optimal setting

When prompted with the main setup menu, please scroll down to "**Restore Defaults**", press "**Enter**" and select "**Yes**" to load default optimal BIOS setup. This will force your BIOS setting back to the initial factory configurations. It is recommended to do this so you can be sure the system is running with the BIOS setting that Portwell has highly endorsed. As a matter of fact, users can load the default BIOS setting at any time when system appears to be unstable in boot up sequence.

7.3 FAQ

Information & Support

Question: I forgot my password of system BIOS, what am I supposed to do?

Answer: You can switch off your power supply then find the JP4 on the ROBO-8113VG2AR SBC to set it from 1-2 short to 2-3 short and wait 5 seconds to clean your password then set it back to 1-2 short to switch on your power supply.

JP4: Clear CMOS Setup



Question: How to update the BIOS file of ROBO-8113VG2AR?

Answer: 1. Please visit web site of Portwell download center as below hyperlink http://www.portwell.com.tw/support/download_center.php

Registering an account in advance is a must. (The E-Mail box should be an existing Company email address that you check regularly.)

http://www.portwell.com.tw/member/newmember.php

- 2. Type in your User name and password and log in the download center.
- 3. Select "Search download" and type the keyword "ROBO-8113VG2AR".
- 4. Find the "BIOS "page and download the ROM file and flash utility.
- 5. Unzip file to bootable USB flash drive which can boot to dos mode. Then execute the "update.bat" or "update.efi". It will start to update BIOS.
 - NOTE: Once you use "update.efi" to update BIOS, it must be get into the SHELL MODE to update BIOS
- 6. When you see the "FPT Operation Passed" message, which means the BIOS update processes finished. Please cut the AC power off and wait for 10 seconds before powering on.

http://www.portwell.com.tw/support/download_center.php

If you have other additional technical information or request which is not covered in this manual, please fill in the technical request form as below hyperlink.

http://www.portwell.com.tw/support/problem_report.php

We will do our best to provide a suggestion or solution for you.

Thanks

Question: The steps of windows7 OS installation with USB3.0 driver.

Answer: 1. Windows 7* installation media does not include the native driver supports for USB 3.0, so during the installation, once you get into the screen for select your preferred language, when the keyboard or mouse connect to the USB 3.0 port, it won't have any response. In order to solve this problem, you could refer the following steps to install the Windows 7 on Skylake platform.

2. Installation needs:

- (1) Preparing the valid copyright of Windows 7 on ISO or DVD, as the following you have administrator access to another working computer (the Admin system) with Windows 7 or later to follow these steps.
- (2) To download and unzip the Windows 7 USB 3.0 driver.
 - https://downloadcenter.intel.com/download/22824/USB-3-0-Driver-Intel-USB-3-0-eXtensible-Host-Controller-Driver-for-Intel-8-9-100-Series-a nd-C220-C610-Chipset-Family
- 3. Create a USB flash drive installer:
 - Using the Windows 7 DVD or ISO image to create a bootable USB flash drive.
 - A. Using Windows USB/DVD Download Tool to create a bootable USB flash drive. You could find this tool in our driver CD or download it via http://wudt.codeplex.com/
 - B. Click the Windows Start button, and click Windows7 USB/DVD Download Tool to execute.
 - C. Choosing the ISO file, type the name and path of your Windows ISO file, or click Browse and select the file from the open dialog box. Click Next.

- D. Select USB device to create a copy on the USB flash drive.
- E. If you are copying the file to a USB flash drive, select your USB device in the drop-down list and click Begin copying.
- F. Then you can see it starts to create the bootable USB device.
- G. It shows the "Bootable USB device created successfully" message after finish all processes.

4. Extract the USB3.0 drivers:

The USB3.0 drivers which you downloaded must make a folder to place the driver. Example: "USB3 Fix". Please create 2 folders in the USB3 Fix folder: "USB3" & "mount". Then extract the USB3.0 drivers and copy the "Drivers" folder into USB3 folder.

5. Get the "boot.wim" & "install.wim" files from USB bootable device:

Please copy those two files to the "USB3 Fix" folder from \source of the root of your USB bootable device.

6. Update the "boot.wim" & "install.wim" files by "dism" command:

Please execute the cmd shell as an administrator. (Click Start on windows 7, type in "cmd" and then right click on the cmd application and choose Run as Administrator.)

Please navigate to the USB3_Fix folder in the cmd shell, and type in the following commands in this order to update the boot.wim file:

- (1) dism /mount-wim /wimfile:boot.wim /index:2 /mountdir:mount
- (2) dism /image:mount /add-driver:"usb3" /recurse

- (3) dism /unmount-wim /mountdir:mount /commit
- (4) Please type the command to get which type of your Win7 O/S.
 - dism /Get-WimInfo /WimFile:install.wim
 - Please select the correct index number for your Win7 O/S. (Example: We used the Win7 Ultimate N then we must choose "index 5")
- (5) Please type the command as below lists.
 - dism /mount-wim /wimfile:install.wim /index:5 /mountdir:mount
- (6) Please type the command as below lists. dism /image:mount /add-driver:"usb3" /recurse
- (7) Please type the command as below lists. dism /unmount-wim /mountdir:mount /commit
- 7. Please copy both two file back to the \source of the root of your USB bootable device.

Then you can install the Win7 O/S which has been included the USB3.0 driver by USB bootable device.

8 Portwell Software Service

Portwell Evaluation Tool (PET)

The Portwell Evaluation Tool (PET) is an API which Portwell's customers can access the GPIO, I2C, SMBus, etc under Windows and Linux OS. For more information please contact Portwell.

Portwell BIOS web Tool (PBT)

The Portwell BIOS web Tool (PBT) is a brand new on-line utility which innovated by Portwell. PBT now is available for Portwell's premiere customers who are able to add customized BIOS logo and change BIOS default settings on American Megatrends (AMI) BIOS. Please contact Portwell for more information.

Portwell EC Auto Test Tool (PECAT)

The Portwell EC Auto Test Tool (PECAT) is a brand new utility which innovated by Portwell. PECAT now is available for Portwell's premiere customers, who are able to Test Embedded Controller Function in UEFI Mode. Please contact Portwell for more information.

9 Industry Specifications

9.1 Industry Specifications

The list below provides links to industry specifications that apply to Portwell modules.

Low Pin Count Interface Specification, Revision 1.0 (LPC) <u>http://www.intel.com/design/chipsets/industry/lpc.htm</u> Universal Serial Bus (USB) Specification, Revision 2.0 <u>http://www.usb.org/home</u> PCI Specification, Revision 2.3 <u>https://www.pcisig.com/specifications</u> Serial ATA Specification, Revision 3.0 <u>http://www.serialata.org/</u> PCI Express Base Specification, Revision 2.0 <u>https://www.pcisig.com/specifications</u>